


**pure-hypr AUDIO**

# SB-200

## USER MANUAL



- 1 Speaker
- 2 Usb C Socket
- 3 Button
- 4 Led Indicator
- 5 Hole For Cord
- 6 Hole For Mic

All User Instructions are shared for SB-200 and SB-300.

### Charging the battery:

1 | Insert the charging cable into the matching USB Charge port on the speaker. The USB plug on the opposite end can be plugged into any 5V powered USB port.

2 | After charging is complete, the LED indicator will turn off.

Note : When music volume goes down and you hear the battery warning signal, this means the battery is too low and the speaker needs to be charged.

### Bluetooth pairing:

1 | a) Turn on the speaker by pressing "**⏻**" button for 3 seconds. The speaker will have a sound signal and blue indicator light.

b) Stereo mode (only for two speakers):

Pair the speakers together before pairing to your device. If you have already paired the **SB-200** to your device, please go to the Bluetooth settings on your device and forget or remove the paired device. Power on two **SB-200s**. Double press "**⏻**" on one **SB-200** speaker. Connected sound signals will alert you when speakers are paired successfully. After the speakers have paired together you can then search for and add the **SB-200** to your device.

- 2 | Turn on your device and activate the Bluetooth function.  
3 | Search for Bluetooth pairing name "**SB-200**" and click to pair.

The speaker will pair automatically and the speaker will have a chime indicating that the connection completed. The blue indicator will light on.

Then, press the "**⏻**" button to answer the call when the call is coming in or take a photo when the camera is open on your device.

- 4 | Turn off the speaker by pressing "**⏻**" button for 4 seconds and the speaker will have a sound prompt.

### Transfer between selfie mode and keyboard mode:

Double click "**⏻**" button of the speaker to transfer the selfie mode and keyboard mode (you will hear a shutter sound). Under selfie mode, one click takes a photo when the camera app is open. (If the camera app is not open, continuously click to turn the volume up.); Under keyboard mode, click once to play/pause. Note: The speaker is in keyboard mode by default.

Visit our website at [www.purehypraudio.com](http://www.purehypraudio.com)  
or call at (888) 661-8333 for more information.

## Specifications

Power Rating	3W
Frequency Response	20HZ-20KHZ
THD	< 1%
S/N	≥ 90DB
Speaker Parameter	4Ω 2W diameter 33mm
Battery	3.7V/ 300mAh
Bluetooth Version	Bluetooth V5.0
Product Size	Φ36.8 × 43mm
Product Weight	47.5g